

SANITATION OF VEHICLES

TIME SCHEDULE OF INDIVIDUAL SANITATION OPERATIONS

Daily Tasks - removal of coarse dirt from the floor of the interior of the driver's cabin and the loading area.

Weekly Tasks - vacuuming of seats and interior spaces, washing of the interior spaces of the driver's cabin and the loading area of vehicles.

Monthly Tasks - washing of the loading area of the vehicle with a disinfectant solution, washing of the exterior of the car as needed and according to the degree of soiling (at least 1 x month).

Disinfectant solutions are prepared by carefully measuring (weighing) doses of disinfectant and water. When disinfecting, it is necessary to respect the suitability of the selection of the disinfectant and the principle of alternating disinfectants to prevent the development of resistance of microorganisms to the long-term used product.

Disinfection is carried out either by a subcontractor or by the carrier, according to a precisely defined procedure, which is recorded as a separate process in the carrier's directive.

Abroad, disinfection is rarely performed and is only carried out when necessary:

- a) when changing the transported goods from medicines to food and vice versa,
- b) in case of contamination with food,
- c) after an accident or crash,
- d) if a contract is signed with the company and a safety data sheet of the used disinfectants and their concentration is submitted.

CLEANING

CLEANING METHODS:

- Mechanical - cleaning of interior walls, floor and ceiling of the vehicle
- Chemical - use of special disinfectants approved by the Chief Hygienist of the SR, with a precisely determined concentration

FLOORS:

Always before washing, any spilled solid (dusty) substances should be collected, swept, or vacuumed on the seats. The floor is washed with warm soapy water and then wiped with clean drinking water. Then the floor is disinfected with a solution of the disinfectant used in the company.

For disinfection, disinfectant solutions intended for surface disinfection are used, prepared according to the procedure and in the concentration as described above.

Automatic equipment is reserved for washing. When washing the floor, it is necessary to thoroughly clean the edges of the floors, in case of heavier soiling, a brush with synthetic bristles is used to remove dirt. All washable surfaces of the car's transport area (floors, walls, doors) are washed.

SEATS:

During cleaning, remove dirt with a vacuum cleaner, in case of heavier soiling, clean the seats with a soapy agent.

EXTERIOR OF THE VEHICLE:

It is cleaned automatically in car washes with running water and detergent. A brush with fine bristles is used to remove dirt so as not to damage the vehicle's paint. The technician continuously provides the necessary material and cleaning agents needed for maintenance. Each driver performs maintenance of the assigned vehicle. The maintenance is recorded in the form - Register of cleaning and disinfection of the cargo area in the means of transport with the date, vehicle registration number and confirmed by signature.

The frequency of cleaning and disinfection is carried out according to the stated sanitation schedule.

- Disinfection is carried out automatically after thorough washing and drying. The disinfectant solution is in a separate container (other than soapy water!) when manually disinfecting hard-to-reach surfaces.
- It is necessary to observe the exposure time of the disinfectant; the disinfected area cannot be re-washed or used within this time.
- After the exposure time has elapsed, it is necessary to wipe the disinfected areas with clean drinking water.
- Disinfectant solutions are prepared by a trained employee of the hygiene and sanitation department.
- After the sanitation is completed, the area must be visually clean and dry.

In Třinec on May 12, 2025

Dominika Rovňaníková

Executive Director of VENTUS trans s.r.o.